



# **DATA SHEET**

## **Ladder Base Support Angles**





- ▲ Ladder Base Support Angle to fasten bottom of ladder to flooring or structure.
- Place ladder in the desired location and fasten the ladder base support by using the fixing listed in installation handbook. Always install fixings through high point of roof profiles.
- △ FastFit ladder system is designed for single person use and rated for maximum 150kg.
- FastFit ladders are manufactured to AS 1657:2018 Standards.





inual



Website




Catalogue




Safety Centre Training

#### Ladder examples below



LADERK002.102



LADERK002.102+BASE

### A FALL RESCUE PLAN SHOULD BE DEVELOPED PRIOR TO USING SAFETYLINK EQUIPMENT

#### © 2018, SafetyLink Pty Ltd, Australia.

Patents: SafetyLink Pty Ltd has a multitude of patents, patents pending, design applications, trademarks and copyrighted documents both lodged and issued. Should you wish to know the progress of our intellectual property on a specific product please email us on <a href="mailto:ip@safetylink.com">ip@safetylink.com</a> and quote the product code.

Doc ID: MKT-889 Version: 7.0

